







# 6901 - Back D





1





2





3





4





5



6




7











8

1x 1x 1x 1x 1x




9

				
1x	1x	1x	1x	1x




# 10





2x 1x 1x






This inset box shows the parts required for step 10: two red 1x1 Technic pins, one grey 1x2 Technic Technic brick, and one grey 1x4 Technic Technic brick.




# 11






# 12

				
1x	1x	1x	5x	1x









# 14



# 15





# 16

